

10'



# SETUP INSTRUCTIONS



### General Setup Instructions


- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.




- For Cleaning Metal, Plex, & Laminate Parts: Use a **MILD NON-ABRASIVE** cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure.
   Heat and UV exposure will warp and fade components.
- Retain all provided Packing Materials.
  All provided packing materials are for ease of repacking & component protection.

## Disassembly

- For loss prevention, tighten all setscrews and locks during disassembly




Hex Tool - Essential for Assembly




Part Identification - Numbering



# MARNING



Spline Connection




Base Plate & Extrusion Connection




DO NOT USE POWER TOOLS



LADDERS OR LIFTS MAY BE REQUIRED



**Extrusion & Lock Connection** 



Engaged Lock





ALL CONNECTIONS MUST BE TIGHTLY SECURED





Top View of Each Level


**Backwall Components** 

















#### **Order #XXXXX - Backwall Assembly**


Item	Qty.	Description
1	1	47.9975"h Lower Curved Extrusion
1A	1	38.5"h Upper Curved Extrusion
2	1	47.9975"h Lower Curved Extrusion
2A	1	38.5"h Upper Curved Extrusion
3	1	47.9975"h Lower Curved Extrusion
3A	1	38.5"h Upper Curved Extrusion
4	2	36.1425"h Backwall Support Extrusion
5/5A	1/1	44"w Lower Horizontal Extrusion
6/6A	1/1	44"w Upper Horizontal Extrusion
7/7A	1/1	23"w Upper Horizontal Extrusion

#### Steps:

- 1) Connect backwall upper and lower verticals together [1] to [1A], [2] to [2A] and [3] to [3A].
- 2) Connect horizontal extrusions together [5] to [5A] and [6] to [6A].
- 3) Attach horizontal assemblies [5/5A and 6/6A] between vertical assemblies [1/1A] and [2/2A].
- 4) Attach horizontal extrusions [7 and 7A] between vertical assemblies [2/2A and 3/3A].
- 5) Attach support leg extrusions [4] to back of verticals [1] and [3], see leg attachment detail.
- 6) Attach graphics to backwall where indicated.









#### **Order #XXXXX - Counter Assembly**

em	Qty.	Description
8	1	Base Plate


9 1 37.476"h Vertical Extrusion

9A 1 Flange Plate

10 1 15.69"w Horizontal Extrusion11 1 18.5"w Horizontal Extrusion

#### Steps:


- 1) Attach base plate to vertical [9].
- 2) Connect horizontals [10] & [11] between vertical [9] and backwalll assembly.
- 3) Attach counter to upper horizontal [11] using mounting plate [9A]









Connect Vertical Extrusion to Base Plate by placing lock into slot and tighten with tool.





#### Counter Top Attachment

Insert screws located on underside of counter into holes on flange plate and secure with wing nuts.





#### **Order #XXXXX - Header Assembly**

Item Qty. Description

12/12A 1/1 6.0257"h Vertical Extrusion 13/13A 1/1 35.74"w Curved Horizontal

#### Steps:

- 1) Connect upper curved horizontals [13] & [13A] together.
- 2) Attach verticals [12] & [12A] to each end of horiozntals as shown.
- 3) Attach header to upper backwall horizontals.

